

Installation Information

NAROWED CONTROL ARMS

*Please read these instructions completely
BEFORE starting your installation!*

When installing narrowed control arms, the rack and pinion must also be shortened to be able to correctly align the suspension. The tie rod ends are now closer in, and there is not enough depth in the tie rod ends to just screw them on further. The rack and pinion ends should be shortened approximately 5/8" per end. Try the assembly. If the jamb nuts run out of thread, the rack may have to be threaded slightly further with a die. If the rack still bottoms out in the tie rod ends, then a small amount more will need to be cut off the ends of the rack. This will then allow ample thread engagement while allowing enough travel for correct alignment.

