

# Installation Instructions

## 1964-1967 MUSTANG SMALL BLOCK MOTOR MOUNT STANDS

*Please read these instructions completely  
**BEFORE** starting your installation!*

Your HEIDTS Hot Rod Shop Motor Mount Stand Kit contains the following items:

- 1) Pair Motor Mount Stands,  
Left & Right
- 2) Base Plates
- 8) 3/8-16 x 1" Hex Bolts
- 2) 7/16-14 x 4-1/2" Hex Bolts
- 8) 3/8-16 Nylock Nuts
- 2) 7/16-14 Nylock Nuts

Bolt your rubber motor mount blocks to your engine block. Bolt the Motor Mount Base Plates to the Mustang II Crossmember using the 3/8-16 x 1" bolts and nuts supplied. Assemble the Mount Stands between the rubber blocks and the base plates as shown using 7/16-14 x 4-1/2" hex bolts and nylock nuts, noting that there are left and right stands. They are offset to the rear so place them on that way. The Stands may need to be trimmed to fit in place. Tack weld the Stands to the Base Plates. After checking for correct engine alignment and clearances, remove the mounts and finish welding. Reinstall Stands and bolt in place. Bolt engine to stands.

